


# How to Size a Double Cylinder



A = Overall Size

B = Internal Size

C = Cam Size (Always 10mm)

D = External Size

**Part Number/Size = ADA (X) (Y) NP**